


ПЕЧЬ ДЛЯ ПИЦЦЫ TATRA PRO 1 M



ПЕЧЬ ДЛЯ ПИЦЦЫ TATRA PRO 1 M

1	MAIN BODY	PF4040E-01	1
2	SIDE COVER	PF4040E-02	2
3	FRONT STAINLESS FRAME	PF4040E-03	1
4	ENAMEL FRAME	PF4040E-04	1
5	OVEN FRONT COVER	PF4040E-05	1
5A	M8 IMBUS PIN BOLT	PF4040E-05A	2
5B	ENAMEL COVER	PF4040E-05B	1
5C	COVER ISOLATION	PF4040E-05C	1
5D	SIGHT GLASS	PF4040E-05D	1
5E	STAINLESS COVER	PF4040E-05E	1
5F	BAKELITE	PF4040E-05F	1
6	COOKING BOILER	PF4040E-06	1
7	COOKING STONE	PF4040E-07	1
8	FEEDING CABLE	PF4040E-08	1
9	FEEDING CABLE SOCKET	PF4040E-09	1
10	INTERIOR LIGHTING LAMP	PF4040E-10	1
10A	SOCKET	PF4040E-10A	1
10B	LAMP	PF4040E-10B	1
10C	LAMP GLASS	PF4040E-10C	1
11	ELECTRICAL MOUNTING PANEL	PF4040E-11	1
12	PANEL	PF4040E-12	1
13	INTERIOR LIGHTING BUTTON	PF4040E-13	1
14	INTERIOR LIGHTING BUTTON PROTECTION	PF4040E-14	1
15	THERMOSTAT CONTROL LAMP	PF4040E-15	2
16	THERMOSTAT BUTTON	PF4040E-16	2
17	THERMOSTAT	PF4040E-17	2
18	RESISTANCE	PF4040E-18	2
19	M6 BLIND NUT	PF4040E-19	2
20	M6 FLAT WASHER	PF4040E-20	2
21	M6 SPRING WASHER	PF4040E-21	2
22	M6 IMBUS PIN BLOT	PF4040E-22	2
23	INSULATION	PF4040E-23	1
24	OVEN FOOT	PF4040E-24	4

				 TATRA