


CUOCIPASTA COMPONENTI COMUNI

Pos	Код	Описание
0001	CR1166930	FLUE GRID [C] M640
0002	CR0588190	PIN [C] DRAINER PASTA COOKER
0003	MA1817201	ASS.GRIGLIA SCARICO
0004	CR0588001	DRAINER [C]
0005	CR0736780	TAP [C] PASTA COOKER
0006	MA1036507500	GASKET [C] 15,60X1,78
0010	MA1033504000	CLAMP [C]
0011	CR0581810	4 WAYS COMMUTATOR [C]
0012	CR0587650	GASKET [C] SHAFT
0013	CR1227600	PIPE [C] D. 72CM
0015	CR0585951	PRESSURE SWITCH [C]
0017	CR0585930	SILICONE RUBBER PIPE [C] D. 4X8
0018	MA15119299	GRAIN [C]
0019	CR0589882	PIPE [C]
0020	CR0731830	PIPE [C] PASTA COOKER 700
0021	SI8206800	EXTENSION [C] DRAIN PASTA COOKER 700
0022	MA15860399	FLANGE [C]
0023	CR0588510	GASKET [C] CONTROL PANEL 900
0024	CR1094330	KNOB [C] SHAFT D. 6
0025	CR0580460	BUSH [C]
0026	CR0584030	METAL LABEL [C]
0029	MACM155200	HANDLE [C] PASTA COOKER DRAIN
0030	MA1515900	SPACER [C] KNOB
0031	CR0682340	NUT [C]
0033	MA1033504000	CLAMP [C]
0034	MA6086113	FOOT ASSEMBLY [C] H. 200
0037	MA1878400	TERMINAL BLOCK [C]
0039	CR0681800	WATER DRAIN [C] TANK PASTA COOKER
0040	MA15203299	SCREW [C] M5X45 UNI EN ISO 4014
0041	CR0588960	VALVE [C]
0042	CR0682880	CONNECTOR [C] PIPE D. 22
0043	MACM161300	CONNECTOR [C] M/F

Apach

CHEF *Line*

ELECTRIC PASTA COOKER



ELECTRIC PASTA COOKER

Pos	Код	Описание
0001	CR0731030R	HEATING ELEMENT [C] 5,6KW 230V PASTA COOKER 700
0002	CR0586210	SUPPORT [C] HEATING ELEMENT PASTA COOKER 900
0003	MACM200100	GREASE [C]
0004	MACM099200	GASKET [C] HEATING ELEMENT
0005	MA15119299	GRAIN [C]
0006	MACM021600	RING NUT [C]
0007	MA52185099	KEY [C]
0008	CR0731850	CRUSCOTTO CUOCIPASTA 700 M80
0009	CR1094330	KNOB [C] SHAFT D. 6
0010	CR0580460	BUSH [C]
0011	CR0589870	METAL LABEL [C]
0013	CR1095040	KNOB [C] SHAFT E15 D. 6
0014	CR0587650	GASKET [C] SHAFT
0015	CR1095240	METAL LABEL [C]P/CP SILKO E15
0016	CR0588510	GASKET [C] CONTROL PANEL 900
0017	CR0582130	NUT [C]
0018	CR0582140	GASKET [C]
0019	CR0588170	6 POLES TERMINAL BLOCK [C] 450V
0020	MACM187301	CONTACTOR [C]
0021	MA1984000	ELECTRIC NOISE FILTER [C]
0022	CR0582120	HEATING ELEMENT BUSH [C] FOR PASTA COOKERS