



Pos	Code	Description
0001	70203	SMALL HOPPER LID
0002	70145	HOPPER SHUTTER
0003	90263	SMALL HOPPER WITH SHUTTER
0004	50501	DISPLAY BOARD
0005	70333	DASHBOARD
0006	50503	CORD
0007	40369	SPOUT
0008	20346	HOOK
0009	70345	FILTER-HOLDER REST
0010	70335	TRAY
0011	85196	GRADUATED DISK
0012	70334	RING COVER
0013	40284	SETTING RING
0014	90242	SUPPORT ASSEMBLY
0015	45124	LMKAS WASHER
0016	70286	RING
0017	912086	SCREW
0018	90300	BURRS
0019	45132	NUT
0020	746822	WASHER
0021	10257	DRIVE HUB
0022	93126	MOTOR
0023	50233	CAPACITOR
0024	20483	BRACKET
0025	50502	ELECTRONIC BOARD
0026	75210	PIN
0027	50170	SWITCH
0028	50137	SUPPORT
0029	50138	BUTTON
0030	50358	WIRING
0031	80135	BOX
0032	12401	GRINDER BODY
0033	45529	FLAP
0034	70198	COVER
0035	70332	PLATE
0036	50161	CORD CLAMP
0037	70140	FOOT
0038	50207	CORD