



ELECTRIC COOKING TOP

Pos	Code	Description
0001	MA1712913	ELECTRIC PLATE [C] 2600W
0003	CR0587230	SPACER [C] M8X13,5
0005	CR1095040	KNOB [C] SHAFT E15 D. 6
0006	MA9003088700	SPRING [C] KNOB
0007	CR0581190	BUSH [C]
0008	CR1095170	METAL LABEL [C] E15
0009	CR0588510	GASKET [C] CONTROL PANEL 900
0010	CR0588850	FLANGE [C]
0011	CR0587500	ORANGE PILOT LAMP [C]
0012	CR0587650	GASKET [C] SHAFT
0013	MA1616100	COMMUTATOR [C]
0014	MA1878400	TERMINAL BLOCK [C]
0015	CR0588170	6 POLES TERMINAL BLOCK [C] 450V
0016	CR0688810	RIGHT SIDE PANEL [C] TOP 700
0016	CR0688820	LEFT SIDE PANEL [C] TOP 700
0017	CR1166930	FLUE GRID [C] M640